

NOTE: SUPPLEMENTARY INSTRUCTIONS READ FIRST!

Snap-In Idler Installation Instructions

Tools Needed	Hardware Provided (Per Shade)	Hardware Needed
5mm Allen Key	Snap-In Idler	None

[*Instruction Pictures Go From Left to Right]

Idlers come pre-installed on end cap (1).

Use Allen-Key to remove set screw and pop out the round bearing (2).

Install shade per instructions.

When installing shade tube place the round bearing onto the round pin (white end of bearing facing out) and slide into bracket (3,4,5,6).

When shade tube is in place, re-install set screw with Allen-Key.

