

## **Magnetic Lock Installation Instructions**

\* Please use these instructions to take the place of steps 4 – 6 of our standard cable instructions.

1. **Install Bottom Rail Magnets to Bottom Rail:** If the magnetic ends of the bottom rail are not installed please do so at this time. Insert the bottom rail into the fabric pocket and insert magnetic ends into bottom rail. Use provided screws to secure.
2. **Plumb Cable:** Use plumb line to plumb from cable hole in housing down to cable mounting surface. Mark exact spot with a pencil.
3. **Install Magnet Base:** Remove bottom center screw from magnetic system and separate the base from the bottom half of the magnetic system. Mount base to the cable mounting surface using appropriate hardware. Be sure that the cable hole in the magnetic base bracket is centered on the cable plumb mark.
4. **Installing the Cable:** **(Note: If this is your first time doing this step be sure it is correct before cutting the cable to length. We recommend a test run first.)** Remove top nut and washer from the threaded adjustment rod. Move bottom nut to just below halfway point. Insert threaded adjustment rod into cable hole in box end cap and replace top nut and washer, loosely hand tighten. With fabric halfway down run cable through bottom rail magnet and top of magnetic system base. Insert cable into magnetic system base bracket and cut cable to length. Install bottom cable lug. Put magnetic system base back together and replace screw. Tension the cable using a combination of loosening the top nut on the threaded adjustment rod and tightening the bottom nut.
5. Repeat on opposite side of shade.