

# Install 3-Prong Electrical Plug

Wiring is as follows:

Ground goes to **GREEN** screw

Black to the **BRASS** screw

White goes to the **SILVER** screw

Tools Needed:

Phillips screwdriver, wire strippers, a utility knife and about 10 minutes.

Strip the ends of the wires and twist them. Insert the wires into the connectors on the plug at noted above, tighten all screws firmly, then replace cover on plug.



**Strip the wires    Insert into correct connectors**



**Internal view**



**Replace cover**