

INSTALLING BOTTOM PULL CORD ON SPRING TENSION SHADES

- Mark the approximate center.
- Remove plastic end cap on one side. (Photo #1)
- Assemble ring to clip. (Photo #1)
- Slide assembled clip and ring to marked center point (Photo #2 and #3).
- Use a pliers with a padded face to squeeze the bottom of the clip until it slightly dents the bottom bar. (Photo #4)
- Put cord pull through ring. (Photo #5)

