

TO REPLACE CITADEL FABRIC PANEL

1. Roll Shade all the way up.
2. Remove the tek screws from the hood and remove hood from box.
3. Remove tube with old fabric from the box and out of the tracks. Make sure fabric is rolled up.
4. Remove the bottom slat from the bottom of the shade by removing the nut and bolt from the plastic inserts. Slide the bottom slat off.
5. Completely unroll the fabric from the tube onto a flat surface. Remove the tube from the fabric.
6. Lay the new fabric on top of the old fabric, making sure it is oriented the same way as the old fabric.
7. Slide the new fabric into the U-Channel on the tube from the end (use silicon spray if you encounter resistance.) Center the fabric on the tube.
8. Roll up the fabric on the tube.
9. Reinstall the bottom slat using the nuts and bolts and plastic inserts.
10. Feed the fabric and bottom slat into the top of the tracks.
11. Reinstall the tube with new fabric into the shade box.
12. Replace hood on box and secure with tek screws
13. Run shade up and down several times to make sure the fabric panel is centered correctly on the tube.

Fabric may have some wrinkles from shipping; these will disappear with some warm weather.