

HOW TO REPLACE THE CRANK GEAR ON A CITADEL SHADE

- Remove set screws from bottom bar.
- Remove front cover from box by removing 1 hood screw from each side.
- Remove cradle idler cotter pin from non-operation side.
- Remove the front cover of the side tracks and the screws that hold the tracks to the mounting surface so that you can take the fabric out of the tracks.
- Remove Roller Tube with fabric. 2 person job, pull roller shade out from idler end and slip off gear end.
- Remove bolts from the outside of end cap on gear side.
- Re-install new gear.
- Reinsert Roller shade and re-install idler cotter pin.
- Feed the fabric into the tops of the tracks and reinstall tracks and front track covers.
- Operate shade a couple of times.
- Re-install front cover to complete.