



Example of 2" thick shims in back of a housing box. Shims can be, but do not *have* to be, the full length of the housing box.

The housing box mounting fasteners must go through the shims and soundly into the structure (header, posts, etc.)