

Replacing the Power Cord

1. Disconnect motor wire and free from housing unit.
2. Uninstall guide options: For cable systems, remove bottom bar eyelets (*do not cut cables*). For track systems, remove tracks.
3. Roller tube and fabric must be removed from exposed brackets or housing box.
Please refer to original installation instructions.
4. Place roller tube and fabric on sawhorses, make sure you are protecting fabric when placing on sawhorses or ground.
5. Looking at crown of motor where motor wire comes out, you will see two tabs, one on each side of motor wire.



6. Using needle nose pliers squeeze tabs towards motor wire.



7. This will release connector so that you may remove existing motor wire.



8. Install new motor wire the same way you removed old motor wire.
9. Slide new motor wire in straight to make sure connection slides in correctly.
10. Follow steps to reinstall from original installation instructions.