

USB Port for Helios Motor



The USB port is underneath the end cap of the solar station on the end that does not have the cord coming out that attaches to the motor. You need to remove the cap to see it. The cap keeps water from getting into the port.