

Slim Line Remote Battery Replacement

1. Remove the screw on the back and the cover.
2. Carefully remove the green circuit board. The battery is on the back.
3. Slide the old battery out.
4. Insert the new battery respecting the correct polarity.
5. Carefully replace the green circuit board with the line of six through-holes towards the metal weight.
6. Replace the back cover using the screw.

