Instructions for 110 Volt Somfy Motor.

IMPORTANT one motor on a

single pole or two on a double pole switch. Additional motors on same switch require special relays

110 Volt Motors Wire to Codes

Motor Cable
It can pass through the center
or side of the motor head.
Raise Yellow cover plate
slightly, reposition cable and
press back into place

NEVER

Wire in Parallel or Use standard Light Switches

Test Cable (rent from Solar-Screen)
It gives installer the ability to
set limits before wiring.
Save time with multiple shades

Unwind about 12 inches of shade material before placing shade in brackets. Take care not to kink the shade material especially Mylar.

See Shade Brackets and Wiring Diagram pictured on the reverse side.

Motor Bracket is equipped with a clip ring that locks shade into place automatically.

Use Pull Off Tool to release if you must remove shade from the bracket.

Note Yellow Cover on Motor. Motor can be located axially in 6 positions-select one that provides access to the Yellow Limit Switch Cover.

Idler is self adjusting spring loaded.

Install shade by pressing into the Self Leveling Nylon Ball on the Idler Bracket and then into the Motor Bracket.

Setting the Down and Up Limits. (*limit the movement Up and Down to the window size*)

Power Shade to confirm Switch operates in the correct direction. If not the wiring is reversed.

#1.Remove Yellow protective Cap exposing both Up and Down Limit Switch.

#2.Depress both Limit Switches-shade will continue to run unless stopped by switch.

Take care not to let shade travel too far in either direction.

#3.Power the shade to the lower limit position-stop motor.

#4.Press Limit Button that is in the direction of the roll.

#5. Power the shade to the upper limit position-stop motor.

#6. Press Limit Button that is the direction of the roll.

#7. Test shade by running Up and Down-If correct replace the yellow cover.

Limits can be changed by pressing the appropriate button and repositioning.


Stop Position

With Limit Button pressed In bring Shade to the desired stop position. Note direction of rotation.

Release Limit Switch button that lies in the direction of rotation by pressing it down again.

Stop is Set


110 Motor Instructions



APPLICATIONS

ONE MOTOR / SINGLE POLE SWITCH

TWO MOTORS / DOUBLE POLE SWITCH




Motor Bracket



Crown Design-with Locking Spring Ring

6 Positions for Motor Head. Set so Limit Switches are reachable.

Free Turning Side (Idler) Spring Loaded-Self Adjusting



Bracket Idler Side

Self aligning Nylon Ball with Bearing Surface



110 A Motor Instructions. Pub