Repairing Wavy Fabric at the Bottom Rail on Roller Shades



Wavy fabric at bottom rail pictured above



Insert a plastic card in between the fabric and the clear plastic Profile in the bottom rail. Slide the card from one side of the rail to the other pushing the fabric back into the rail. Repeat as necessary.



Results of this repair pictured above