



Inteo Chronis RTS Timer (Quick Reference Guide)

Programming the Chronis: Programming the Chronis depends on the item it will be controlling. For instance: Centralis, Eolis, Altus. Follow the specific programming instructions for each item it will be controlling. The programming button of the Chronis is located under the switch cover, right above the display. “Prog” will appear on the display as you press it.

On/Off: Turn the Chronis **Off** by pressing the “+”. You can still use it manually but all automatic functions will be turned off. Press the “-“ to turn it back **On**.

To Set or Reset the Time: Quickly press “Set” while the **time** is displayed. It will begin to flash. Use the “-“ or “+” to change the time (military time). Quickly press “Set” when done to confirm it.

To Set or Reset the Day, Month or Year: Quickly press “Calendar” and then “Set” and the day will begin to flash. Use “-“ or “+” to change the day. When done, press the “Up” button and the month will begin to flash. Use the “-“ or “+” to change it. When done, press the “Up” button and the year will begin to flash. Use “-“ or “+” to change it. Quickly press “Set” when done to confirm it.

Timer Settings: This setting allows you to open and close the application at different times each day (**7 day timer**). Press and **hold** “Set” until a second (smaller) time is displayed below the normal time.

Up Times: Quickly press “Set” and the time begins to flash. Press the “Up” button and the current (smaller) up time flashes along with the up arrow and day (**1 = Monday**). Press “Calendar” to select the day. Use the “-“ or “+“ button to change the up time. Setup each day individually or for weekly programming. To turn it “Off”, set it between **23:59** and **0:00**. Quickly press “Set” when done to confirm it.

Down Times: Quickly press “Set” and the time begins to flash. Press the “Down” button and the current (smaller) down time flashes along with the down arrow and day. Use the “-“ or “+“ button to change the down time. Press “Calendar” to select the day. Setup each day individually or for weekly programming. Set it between **23:59** and **0:00** to turn it “Off”. Quickly press “Set” when done to confirm it.

Vacation Security Setting (SEC): This setting takes the normal “Timer Settings” and randomly changes them plus or minus **15 minutes** each day to give the appearance that your house is occupied. Press and **hold** “Set” until “SEC” appears on the display.

Cosmic 1 Setting (COS1): This setting **opens** and **closes** at **sunrise** and **sunset**. Press and **hold** “Set” until (COS1) appears on the display. You can enter differential and cutoff times to customize this setting.

Differential Times: Allows you to change the **Up (sunrise)** time or **Down (sunset)** time by plus or minus 1hr 59mins. Quickly press “Set” and the time begins to flash. Press the “Up” button to choose the up differential or the “Down” to choose the down differential. Use the “-“ or “+” to change the differential time. Quickly press “Set” when done to confirm it. Check and set the cutoff times (see below).

Cutoff Times: Modifies the differential times and limits the earliest it will go up at sunrise or latest it goes down at sunset. Quickly press “Set” and the time begins to flash. Press the “Up” button twice for the **up** cutoff time or the “Down” button twice for the **down** cutoff time. An (S) will appear next to the (smaller) cutoff time. Use the “-“ or “+” to change it. Set it between **23:59** and **0:00** to turn it “Off”.

Cosmic 2 Setting (COS2): This setting **opens** at the individual “Timer Settings” and **closes** at the “Cosmic 1” settings (this includes the differential and cutoff times of COMS1). Press and **hold** “Set” until (COS2) appears on the display.

Important: Please read the complete instructions prior to using this quick reference guide.