

CHAIN TENSION DEVICE Installation Instructions

GETTING STARTED

IMPORTANT: The included screws can be screwed directly into wood. When attaching to drywall or metal, use anchors that are designed for such substrates. See your hardware store or supplier for guidance on appropriate anchors for your substrate.

TOOLS NEEDED:

- Pencil
- Phillips head screwdriver
- Tape measure
- Power drill

PARTS INCLUDED:



2 LARGE SCREWS



2 SMALL SCREWS



BRACKET
Select option that suits installation

STEP 1: POSITION TENSION DEVICE



The tension device must be installed to make the shade fully operable.

PROCEDURE: To begin installation, first slide the tension device to the bottom of the bead chain.

While holding the tension device in one hand, pull the plunger away from the bead chain with the other hand. Lift the bead chain out of the bead locking groove and slide the tension device to the bottom of the chain loop.

Pull the tension device down until the bead chain is fully tensioned (plunger will be at the top) and then move the tension device up approximately $\frac{1}{8}$ " (3mm).

Mark the screw hole locations on the wall with a pencil.



STEP 2: MOUNT TENSION DEVICE

GENERAL NOTE: If mounting into wood, pre-drill screw holes and then install the tension device using the 2 large screws provided.

If not securing into wood, use appropriate anchors for the substrate and follow anchor manufacturer's instructions.

USING A BRACKET: Align the mounting bracket sight holes with the pencil marks and fix the bracket.


Press the tension device onto the mounting bracket posts. Carefully install the 2 small screws provided, through the tension device into the mounting bracket using a Phillips head screwdriver.

DO NOT OVER-TIGHTEN.


INSIDE MOUNT




OUTSIDE MOUNT



FLOOR MOUNT



SIDE MOUNT



FLOOR MOUNT INSTRUCTIONS:

Securely fix the floor mount bracket to desired location.

Assemble with chainhold & chain.

Adjust the length of the bead chain so that the plunger is $\frac{1}{8}$ " (3mm) below its top position. Adjust chain length by removing balls and reassemble with pliers or a chain connector (sold separate).